

MasterBox D-100 *Naturelle* by Thomil



ECOLABEL UNIVERSAL DETERGENT FOR
AUTOMATIC DISHWASHER

Usage Pictograms:



PACKING:

NALV002: One (1) 6kg bag

Signaling Pictograms:



ECOLABEL REGISTRATION NUMBER:
ES-MD/038/00002



**REGULATION 66/2010 FROM THE
EUROPEAN PARLIAMENT & EUROPEAN
COUNCIL**

BIODEGRADABLE SURFACTANTS ACCORDING TO:
Regulation 648/20047CE

Description:

Very effective ultra-concentrated liquid detergent for automatic washing of dishes, containers and utensils in industrial machines and self-cleaning ovens. Suitable for any water hardness up to 40°HF. NON-foaming product in high agitation and temperature environments. It provides effective cleaning due to its composition of surfactants. Facilitates rinsing. Completely biodegradable.

Applications:

For cycle or continuous tunnel washing machines. Effective in washing at temperatures of 50-65°C.

How to use:

Apply with a peristaltic dispenser in doses of 0.6 to 2 g per liter of water with an injection mechanism in the washing bath in washing cycles of 2 to 4 minutes or with a peristaltic dispenser in doses of 0.5 to 1.5 g. per liter of water with injection mechanism in the washing bath in tunnels with washing paths of 1.5 to 3 minutes

Technical characteristics:

*SPECIFICATIONS:

ASPECT:	Transparent Liquid
COLOR:	Yellowish
SCENT:	Characteristic
DENSITY (20°C):	1280 – 1320 kg/m ³
pH:	13 – 14

*COMPOSITION: Aqueous mixture based on complexing agents, alkalis and dispersants.

Conservation and Storage:

Store in the original container tightly closed, protecting it from cold and intense heat. Avoid freezing. Do not expose it to direct solar radiation

Safety and handling:

DANGER. Contains: Potassium Hydroxide, Sodium Hydroxide. Causes severe skin burns and serious eye damage. May be corrosive to metals. Wear protective gloves/clothes/goggles. IF SWALLOWED: Rinse mouth. DO NOT induce vomiting. IN CASE OF CONTACT WITH SKIN (or hair): Immediately remove all contaminated clothing. Rinse skin with water or shower. IN CASE OF CONTACT WITH EYES: Rinse carefully with water for several minutes. Remove contact lenses when present and can be done easily. Continue with washing. Dispose of contents/container in accordance with regulations on hazardous waste or packaging and packaging waste respectively. Do not eat. Keep out of reach of children. Restricted to professional uses. Keep only in the original container.

Warning:

In the event of an accident, consult the Medical Toxicological Information Service at 91 562 04 20.

Our TECHNICAL DEPARTMENT will answer without obligation any doubt or query about the product or its application.
Tel. (+34) 91.691.02.63

